



## DIGITAL VOICE RECORDER USER MANUAL



MODEL: VR-120


### -OVERALL VIEW:



### -FEATURES:

- . Aluminum alloy material
- . One-touch recording
- . Type-C USB
- . Recording LED indicator
- . Built-in lithium battery
- . Play with headphones
- . Memory size: 64GB
- . Storage time of 64GB memory: 88 hours
- . Recordformat: WAV,1536 kbps
- . Recording time of full charged battery: 10.5 hours Recharge time: 1.5 hours
- . Dimension: 48x31x10 mm

## -WHAT' S IN THE BOX:



Manufacturer: Shenzhen Viklink Technology Limited



Website: [www.viklink.com](http://www.viklink.com)  
Email: [service@viklink.com](mailto:service@viklink.com)

## -POWER ON/RECORD:



Slide the “POWER/RECORD” button to the left to start record, the LED indicator will turn red.

## -POWER OFF/ STOP RECORD:



Switch the “POWER/RECORD” button back to its original position, the recording will be stopped and saved.

## -SET DATE/TIME:

Connect the recorder to the computer, find the tool from the route:  
Removable disk >> Set Time folder >> Set Time,  
Double-clicking this tool will synchronize the recorder with the computer time, so that the recording files will be named according to the actual recording date.

## -PLAYBACK ON LOCAL UNIT:

Connect to the wire controlled earphone, switch the “Power/Record” button to power on the recorder, push the “playback” button of the earphone to play the current file, push it again to stop.

### -Vol+/Vol-:

Push the volume button to increase/decrease the volume.

### -Previous/Next:

Double click the Vol+/Vol- to select the file one by one.

## -INDICATOR LIGHT:

Recording: RED led will turn on all the time.

Playback: RED led will turn on all the time,  
(connect to the earphone).

Low battery: Red led flash quickly,  
(0.2~0.3s / time, flash 3 times).

Full memory: RED led will turn on and last 10seconds,  
it will power off automatically,  
please connect to computer,  
transfer or delete files to free memory.